




Inaktivierung von HCV und HIV

PD Dr. Eike Steinmann

Centre for Experimental and Clinical Infection Research


Institute of Experimental Virology, Twincore*

*joint venture between Medical School Hannover and Helmholtz Centre for Infection Research



Hepatitis C Virus (HCV) Profile

Family:	<i>Flaviviridae</i>
Genus:	<i>Hepacivirus</i>
Species:	<i>Hepatitis C virus</i> (7 genotypes)
Size:	50-60 nm
Genome:	(+) ssRNA, ~9.6 kb
Prevalence:	160 million patients
Therapy:	PEG-IFN+Riba, DAAs




Ways of HCV Transmissions

drug abuse



medical procedures



transfusion



sex






vertical




other



Virucidal testing using surrogate viruses

<u>testvirus</u>	<u>surrogate-virus</u>	
Hepatitis B Virus	Duck hepatitis B virus (DHBV)	
Norovirus	feline Calicivirus (FCV) murine Norovirus (MNV)	
Hepatitis C Virus	bovine viral diarrhea virus (BVDV)	


HCV infection system



Wakita and Pietschmann et al., Nat Med 2005



Virucidal efficacy of different alcohols against HCV

Quantitative suspension:





Effect of ethanol, 1-propanol and 2-propanol on HCV/BVDV




HCV







BVDV





HCV stability and inactivation in suspension




Effect of different disinfectants against HCV




Inactivation of HCV: Triton-X and paraformaldehyde



Mechanisms of viral inactivation methods against hepatitis C virus



- Triton
- Ethanol
- 2-Propanol
- PVP-I




- UV






- Heat




Mechanisms of hepatitis C virus inactivation






Establishment of a HCV carrier assay



Survival of dried HCV on inanimate surfaces




Development of a drug transmission assay




Inactivation of HCV in blood products




Methylene blue is a phenothiazine dye.
Dyes of this class can enter the nucleic acid structure, and bind closely to the Guanosine residues of the DNA/RNA.



Following photoactivation in the region of 590 nm,
the dye is able to chemically damage the genetic
material, disrupting viral replication and infectivity.




Sample	\log_{10} TCID ₅₀ ± SD	\log_{10} reduction factor
spike bef. MB	5.41 ± 0.22	
0 J/cm ² after MB	5.29 ± 0.16	0.12
10 J/cm ²	≤3.15	≥ 2.26
20 J/cm ²	≤3.15	≥ 2.26
40 J/cm ²	≤1.58	≥ 3.83
120 J/cm ²	≤1.58	≥ 3.83





Sample	\log_{10} TCID ₅₀ ± SD	\log_{10} reduction factor
after spiking	5.61 ± 0.54	
0.05 J/cm ²	3.80 ± 0.12	1.81
0.1 J/cm ²	2.81 ± 0.12	2.80
0.2 J/cm ²	≤ 0.62	≥ 4.99


Thermo-stability of seven Hepatitis C virus genotypes in vitro and in vivo




Inactivation of HCV in human mother's milk



Fatty acid	Conc. [mg/ml]	RF	SD
Butyric acid	4:0	10	- 0.17 ± 0.53
Caproic acid	6:0	10	≥ 3.71 -
Caprylic acid	8:0	10	≥ 3.71 -
Capric acid	10:0	5	≥ 3.71 -
Lauric acid	12:0	5	≥ 3.71 -
Myristic acid	14:0	20	0.96 ± 0.71
Palmitic acid	16:0	20	0.58 ± 0.18
Stearic acid	18:0	20	1.08 ± 0.18
Palmitoleic acid	16:1	2	≥ 2.46 ± 1.7678
Oleic acid	18:1	10	≥ 3.71 -
Elaidic acid	18:1	20	0.21 ± 0.35
Linoleic acid	18:2	5	3.46 ± 0.3536
Linolenic acid	18:3	5	≥ 3.71 -
Arachidonic acid	20:4	1	≥ 3.71 -





Inactivation of HCV in human mother's milk



Pfaender et al. *Journal of Infectious Diseases* 2013

Editorial Jhaveri: Protection against HCV and other env viruses: „why breast is the best“





Inactivation of HCV and HIV by microwave!?



X Control ● 90 Watt ▲ 180 Watt ▼ 360 Watt ◆ 600 Watt ■ 800 Watt ----- Background


Inactivation of HCV and HIV by microwave

× Control ● 90 Watt ▲ 180 Watt ▼ 360 Watt ◆ 600 Watt ■ 800 Watt ----- Background




Inactivation of HCV and HIV by microwave

A)



B)



Acknowledgement

Twincore, Institute of Experimental Virology



Martina Friesland

Juliane Dörrbecker

Stephanie Pfänder

Aci Siddharta

Anggakusuma

Daniel Todt

Michael Engelmann

Stephanie Walter

Svenja Drave

Martinea Friesland

Christine Goffinet

Thomas Pietschmann

Brill & Partner

German Red Cross

